



Existing Lawn Installation Instructions

1. Lay your Lite Edge on top of the lawn to create a template for your new edges. Staple the Lite Edge in place lightly, and trim the edge vertically using a spade to the contours of your design.



2. Slice horizontally with a turf knife or similar, underneath the existing turf ready to accept the Lite Edge. An edge tool may help here.



3. Turn back the turf and slot the Lite Edge into place lining the Lite Edge up with the newly trimmed lawn edge.



4. Staple the Lite Edge firmly in place using staples. (sold separately) Fill in and level off the indentations of the base using lawn sand



5. Roll back the turf and trim neatly so that the turf is slightly above the top of the Lite Edge. Water well.

